
Service Manual

Built-in Series

Market Model	Product Model	Product Code
HS-267LEN.BI	CE-BC205CX-JT	22031010006402
MDRE288FG***		



The picture in this service manual is only for reference, and specific appearance and configuration are subject to the real product.

This manual mainly teaches the method, the specific work skill needs engineer to accumulate through the daily work.



WARNING

Important Safety Notice

There are special components used in this equipment which are important for safety. These parts are marked by Δ in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.



WARNING

Important Safety Notice

The Maintenance Manual is only for the use of maintenance personnel with certain experience and background in electrical, electronic and mechanical field.

Any attempt to repair main devices may lead to personal injury and property loss. Manufacturers or distributors are not responsible for the content of the Manual and interpretation thereof.

Contents

1. SIGNIFICANT UPDATE NOTES	5
2. SAFETY WARNING CODE	6
2.1 Warning for operation safety	6
2.2 SAFETY INSTRUCTION FOR REFRIGERANT	8
3. INSTALLATION AND COMMISSIONING	g
3.1 HANDLING	<u>c</u>
3.2Door Disassembly and Assembly	g
3.3 Installation location	g
3.4 LEVELING OF THE REFRIGERATOR	12
3.5 LEFT OR RIGHT OPEN-DOOR REVERSAL	12
4. MAIN PARTS AND EXTERNAL DIMENSION	14
4.1 MAIN PARTS	14
4.2 EXTERNAL DIMENSION	15
4.3 MIDEA PRODUCT SERIAL NUMBER AND LOCATION	15
5. ELECTRIC CONTROL SYSTEM	17
5.1 ELECTRICAL PARAMETERS	17
5.2 CIRCUIT DIAGRAM	18
5.3 WIRING DIAGRAM	18
6.REFRIGERATION SYSTEM	20
6.1 REFRIGERATING PIPING SYSTEM	20
6.2 COOLING PIPELINE AND DRAIN PIPE INSIDE THE CABINET	20
6.3 CIRCULATING ROUTE OF COOLING AIR	21
6.4 WELDING POINTS IN CHAMBERS OR FOAM LAYER (NONE)	21
6.5 PIPE WELDING POINT IN THE COMPRESSOR CASE	22
7. DISMANTLING OF PARTS	23
7.1 Parts on the door	23
7.2 PARTS INSIDE THE REFRIGERATOR	23
7.3 LIGHT SYSTEM	24
7.4 AIR DUCT COMPONENTS REFRIGERATING CHAMBER AND DAMPER (NONE)	25
7.5 AIR DUCT COMPONENTS IN FREEZING CHAMBER AND FAN MOTOR (NONE)	25
7.6 EVAPORATOR AND DEFROST SYSTEM	25
7.7 COMPRESSOR CASE	
7.8 DISPLAY CONTROL BOARD	
7.9 Main control board	30
8. TEMPERATURE SENSING SYSTEM	32
8.1 Position of Sensors	32

8.2Replacement of sensors	32
8.3 SENSOR WITHOUT TERMINAL REPLACEMENT	
8.4 Sensor resistance (R/T)	
9. FUNCTION AND OPERATION	35
9.1 DISPLAY OPERATION PANEL	35
9.2 TEMPERATURE CONTROL	35
9.3 MODE SETTING	35
9.4 Open door alarm (None)	36
9.5 FAULT CODE AND SOLUTIONS	36
9.6 DEFROSTING FUNCTION	36
9.7 TEST MODE	36
10. COMPRESSOR	39
10.1 COMPRESSOR ON AND OFF CONTROL SPECIFICATIONS	
10.2 INVERTER BOARD FAULT ANALYSIS	39
11. TROUBLESHOOTING METHOD	42
11.1 ERROR CODE E0	
11.2 ERROR CODE E1 / E2 / E3 / E4 / E5 / E7 / E8 / EE / C9 / CC / F4	43
11.3 ERROR CODE E6	44
11.4 ERROR CODE EF	45
11.5 ERROR CODE EH	
11.6 ERROR CODE EP	
11.7 ERROR CODE CA	
11.8 NOT COOLING IN ALL THE CHAMBERS	
11.9 POOR COOLING IN ALL THE CHAMBERS	
11.10 OVERCOOLING IN THE REFRIGERATED CHAMBER	
11.11 NOT & POOR COOLING IN THE REFRIGERATED CHAMBER	
11.12 NO WORKING OF COMPRESSOR	_
11.13 CONDENSATION & FROST	
11.14 DISPLAY PANEL FAILURE	_
11.15 LIGHT FAILURE	
11.16 NO WATER FROM THE ICE & WATER DISPENSER	
11.17 NO ICE FROM THE ICE & WATER DISPENSER	
11.18 Noise	58
12. MAINTENANCE TOOLING, EQUIPMENT AND MATERIAL	59
13. PRODUCT EXPLODED VIEW AND SPARE PARTS LIST	63

1. Significant update notes

(SM No.)	Date	Author	Description

2. Safety Warning Code

2.1 Warning for operation safety

Important Safety Instructions



CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN





This symbol indicates that dangerous voltage constituting a risk of electric shock is present within your freezer.



This symbol indicates that there are important operating and maintenance instructions in the literature accompanying your freezer.

WARNING

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this appliance near water.
- 6) Clean only with a damp cloth.
- 7) Do not block any ventilation openings.
- 8) Install in accordance with the manufacturer's instructions.
- **9)** Do not install near any heat sources, such as radiators, heat registers, stoves, or other apparatus that produce heat.
- **10)** Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- **11)** Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the appliance.
 - **12)** Do not attempt to modify or extend the power cord of this appliance.
- **13)** Unplug this appliance during lightning storms or when it will not be used for long periods of time.
- **14)** Make sure that the available AC power matches the voltage requirements of this appliance.

6

CONNECTING ELECTRICITY

↑ WARNING Electrical Shock

Hazard.

Plug into a grounded 3-prong outlet.

Do not remove the ground prong.

Do not use an adapter.

Failure to follow these instructions can result in death, fire, or electrical shock.



WARNING

Electric Shock Hazard

Failure to follow these instructions can result in electric shock, fire, or death.

- 1) **WARNING**–Keep ventilation openings, in both the freezer and the built-in structure, clear of obstruction.
- **2) WARNING**—Do not touch the interior of the freezer with wet hands. This could result in frost bite.
- **3) WARNING**—Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
 - **4) WARNING**—Do not damage the refrigerant circuit.
- **5) WARNING**—Do not damage the refrigerant tubing when handling, moving, or using the freezer.
- **6) WARNING-DANGER**—Never allow children to play with, operate, or crawl inside the freezer. Risk of child entrapment. Before you throw away your old freezer:
 - 6-1) Take off the doors
 - 6-2) Leave the shelves in place so that children may not easily climb inside
 - 7) Unplug the freezer before carrying out user maintenance on it.
- 8) This freezer can be used by children age eight years and older and persons with reduced physical or mental capabilities or lack of experience and knowledge if they are given supervision or instruction concerning the use of the freezer in a safe way and understand the hazards involved. Children should not play with the freezer. Cleaning and maintenance should not be performed by children without supervision.
- **9)** If a component part is damaged, it must be replaced by the manufacturer, its service agent, or similar qualified persons in order to avoid a hazard.
- **10)** Please dispose of the freezer according to local regulations as the freezer contains flammable gas and refrigerant.
- **11)** Follow local regulations regarding disposal of the freezer due to flammable refrigerant and gas. All refrigeration products contain refrigerants, which under the guidelines of federal law must be removed before disposal. It is the consumer's

responsibility to comply with federal and local regulations when disposing of this product.

- **12)** This freezer is intended to be used in household and similar environments.
- **13)** Do not store or use gasoline or any flammable liquids inside or in the vicinity of this freezer.
- **14)** Do not use extension cords or ungrounded (two-prong) adapters with this freezer. If the power cord is too short, have a qualified electrician install an outlet near the freezer. Use of an extension cord can negatively affect the freezer's performance.

Grounding requirement

This freezer must be grounded. This freezer is equipped with a cord having a grounding wire with a grounding plug. The plug must be inserted into an outlet that is properly installed and grounded.

Improper use of the grounding plug can result in a risk of electric shock. Consult a qualified electrician or service person if the grounding instructions are not completely understood, or if doubt exists as to whether the freezer is properly grounded.

2.2 Safety instruction for refrigerant



Keep flammable materials and vapors, such as gasoline, away from freezer. Failure to do so can result in fire, explosion, or death.



DANGER–Risk of Fire or Explosion. Flammable Refrigerant Used. To Be Repaired Only By Trained Service Personnel. Do Not Use Mechanical Devices. Do Not Puncture Refrigerant Tubing. CAUTION–Risk of Fire or Explosion. Flammable Refrigerant Used. Consult Repair Manual/Owner's Guide Before Attempting To Service This Product. All Safety Precautions Must be Followed. CAUTION–Risk of Fire or Explosion. Dispose of Properly In Accordance With Federal Or Local Regulations. Flammable Refrigerant Used. CAUTION–Risk of Fire or Explosion Due To Puncture Of Refrigerant Tubing; Follow Handling Instructions Carefully.


Flammable Refrigerant Used.

3. Installation and commissioning

3.1 Handling

Handling

- 1)Protect the refrigerator during moving it, same as shown as right photo, please move it by handcart with cushion
- 2)Remove all packing materials and bottom cushion, then move into house for placement
- 3)After moving it to appropriate location, wait for 2 hours before power on.




3.2Door Disassembly and Assembly

The refrigerator door needs to be dismantled if it cannot enter the room in the whole.


3.3 Installation location

Refrigerator is installed in the cabinet and the size requirements such as the right figure. **Thinckness of cabinet plank** Installation Steps**


- Push the refrigerator into the cabinet and adjust it to make sure the edge fold of top baffle completely touch the top edge of the cabinet, and the limit hook of supporting leg completely touch the bottom edge of the cabinet.
- 2) Fix the supporting leg with screws, then install the screw caps.




3) Fix the top baffle to the top of the cabinet inner with screws, then install the screw caps.



4) Open the refrigerator door to the maximum angle and open it to the corresponding position. Slide the stopper so that its inner edge aligns with the lower edge of the refrigerator door, then secure the stopper to the cabinet door with screws and install the nut. Replace the fixed positions of the adjustable base and bottom hinge, and then secure them again.




5) Take out the sealing strip from accessory bag, and press it in the gap between the cabinet and the refrigerator. Installation is completed.



3.4 Leveling of the refrigerator

Leveling of the refrigerator	
The refrigerator does not need to be leveled.	\


3.5 Left or right open-door reversal



5. Assemble the hole caps, remove the fixed block of fridge door and rotate it for 180°, assemble it on the other side of the refrigerator door. 6. Finished

4. Main parts and external dimension

4.1 Main parts



1 Control panel

3 Fruits and vegetables box


2 Glass shelf

4 Door tray

(The picture is only for reference, and specific appearance and configuration are subject to the real product)

4.2 External dimension

Description	Code	Size (mm)
Width	Α	540
Overall Height	В	1255
Depth to match the cabinet	С	465
Overall Depth	D	550
Height to match the cabinet	E	1200



(The picture is only for reference)


4.3 Midea product serial number and location

1) **Product Serial Number** — Including order number, production date and other information. When the product occur problem, it needs to be recorded or photographed and provided to us.



15

2) Paste location




Some products also have S/N on the lower part of the right side of the Cabinet.

5. Electric control system

5.1 Electrical parameters


Applicable Model	HS-267LEN.BI		
Product Model	CE-BC205CX-JT		
Rated Voltage	200-240V、50Hz		
Item	Specification		
Refrigerant	R600a		
Compressor	DZ35Z1A		
Starting device type	Inverter		
The COP of compressor	1.63(W/W)		
The max cooling capacity of compressor	70W		
Winding resistance of compressor wiring	U-W: 22.6Ω±7%		
terminal (20°C)	U-V: 22.6Ω±7%		
terrimar (20 °)	W-V: 22.6Ω±7%		
Winding resistance picture	U V		
Starter(PTC)	None		
Overload protector(OLP)	None		
Integrate PTC+OLP	None		
Inverter driver board	None		
Capacitor	None		
Power filter (EMI)	None		
Power reactor (EU EMC)	None		
Compensation heating wire	None		
Motor			
Fan motor of the freezing chamber	None		
Fan motor of the refrigerating chamber	None		
Electric damper	None		
Lights			
Lights inside the refrigerating chamber	12V/2W		
Lights inside the freezing chamber	None		
Others Lights	None		
Switch of the light	■Mechanical switch		
	□Magnetism control switch		
Defrosting parts			
Defrosting sensor	NTC B3839 (B5/25=3839K±2%)		
Fuse in freezing chamber	None		
Defrost heater in freezing chamber	None		

5.2 Circuit diagram




5.3 Wiring diagram






6.Refrigeration system


6.1 Refrigerating piping system



6.2 Cooling pipeline and drain pipe inside the cabinet



6.3 Circulating route of cooling air



6.4 Welding points in chambers or foam layer (None)

6.5 Pipe welding point in the compressor case




Pipe welding point	Pipe outer diameter (mm)		
1-The outlet of the return air heat exchanger tube and the	Copper pipe: Ф6.0	Copper pipe: Ф6.0	
inlet of the suction connecting tube	Copper pipe. 40.0		
2-Integrated condenser outlet with filter drier inlet	Steel pipe: Ф4.0	Copper pipe: Ф4.0	
3-One-piece condenser inlet and rear condenser outlet	Steel pipe: Ф4.0	Steel pipe: Ф4.0	
4-Filter drier outlet with capillary inlet	Copper pipe: Ф2.8	Copper pipe: Ф1.8	
5-Compressor process tube inlet and process tube outlet	Copper pipe: Copper pipe: Φ6		
	Ф7.17	Copper pipe. 40.0	
6-The outlet of the suction connection pipe is connected to	Copper pipe: #6.0	Copper pipe:	
the suction pipe of the compressor	Copper pipe: Ф6.0	Ф7.17	
7-Compressor exhaust pipe outlet and evaporation pipe inlet	Steel pipe: Ф5.17	Steel pipe: Ф4.0	
8-Evaporation tube outlet and integrated condenser inlet	Steel pipe: Φ4.0	Steel pipe: Ф4.0	

7. Dismantling of parts

7.1 Parts on the door


Door seal is installed into door liner groove. 1)Open the refrigerator door. 2)Take the door seal out of door liner. Door tray While squeezing it inward, lift up the baffle and take it out from refrigerator liner.

7.2 Parts inside the refrigerator



Shelves

1) Lift up the division plate with a proper force and pull it out towards yourself.



7.3 Light system

Light

The light is located on the right side of the refrigeration room.

- 1) Pry off the hole cover on the temperature control box with a blade, and then use a screwdriver to unscrew one screw of the temperature control box.
- Remove the temperature control box component and unplug and release the connection terminal between the box harness and the LED light
- Use a screwdriver to pry open the lampshade, and then pry off the LED light panel from the temperature control box
- 4) The reverse process can complete installation.













Light switch

- 1) There is a light switch on the side wall of the refrigerating chamber.
- 2) Loosen the hook with small normal screwdriver and pull out the switch until the wire connector reveals.
- 3) The reverse process can complete installation.





7.4 Air duct components refrigerating chamber and damper (None)

7.5 Air duct components in freezing chamber and fan motor (None)


7.6 Evaporator and Defrost system

Evaporator in freezing chamber	
Within the foam layer, not repairable	1


7.7 Compressor case

Rear cover	
	None
Compressor and the cooling system pipe	


1) Cut off the power, remove the goods in the refrigerator, with the tape to make the door fixed firmly and prevent the door dropping when the refrigerator dumping.



2) Place the refrigerator in an area that is open, ventilated, and away from fire sources. Then placing on an operating table and securing it firmly.




- 3) Cut off the compressor pipeline.
- -1 Cut off the process pipeline.
- -2 Cut off the low-pressure muffler.
- -3 Cut off the high-pressure exhaust pipe.




4) Remove the protective cover

- -Two screws outside
- -Pry the protective cover slowly from the upper part,
- -Pull it out and remove it.




5) Remove the starter and protector


Unplug the starter and protector (you can use a screwdriver to pry it slowly)




6) Loosen the screw of the compressor bottom plate, remove the floor together with the compressor from the box.




7) Use the wrench to remove the bolts by steps 4567, replace the compressor and reverse process can complete installation.



8) Use Pipe cutter cut off the condenser tube 3, then Shear off capillary 9 by the capillary tube scissors.



- 9) Replace the compressor and welding the compressor pipeline.
- Welding the process pipeline.
- Welding the low-pressure muffler.
- Welding the high-pressure exhaust pipe.



As welding rod 10) Replace the filter, Cu-Fe tubes welding 13 used Ag welding rod, Cu-Cu tubes welding used Cu welding rod. 11) Vacuum system, The degree of vacuum below 3Pa. 12) Perfusion refrigerant. 13) Use the vise grip pliers clamp the middle of the process pipe, then seal welding process tube 15 16. Piping system in the compressor case main control board box assembly 7. compressor 2 Back condenser (exit) 8evaporation tube (enter) 9.evaporation tube 3 Integrated condenser(enter) (exit) 10.Back condenser (enter) 4 Integrated condenser(exit) 11. Power wire **5**dry filter 6 suction transition tube



7.8 Display control board

Display control board

The display and control board is located on the right side of the refrigeration room

- Pry off the hole cover on the temperature control box with a blade, and then use a screwdriver to unscrew one screw of the temperature control box.
- Remove the temperature control box component and use a screwdriver to remove the two screws that secure the display and control board
- Afterwards, unplug the terminals between the display and control board and the box harness to remove the display and control board
- 4) The reverse process can complete installation.












7.9 Main control board

Main control board

- 1) The main control board installation box is located on the left side of the press compartment
- 2) Use a cross screwdriver to loosen the two screws that secure the main control board installation box and one screw that secures the power cord grounding wire, and then remove the main control board installation box by hand
- 3) Use your hand or a flat screwdriver to pry open the installation box cover
- 4) Use a screwdriver to loosen one screw that secures the power cord card, unplug the power cord terminal, and remove the power cord
- 5) Unplug the main control board terminal, use a cross screwdriver to loosen one screw that fixes the main control board, and remove the main control board;



6) Replace the master control board in reverse steps.












8. Temperature sensing system

8.1 Position of sensors




8.2Replacement of sensors

Sensor


Sensor in refrigerator chamber

- 1) Remove the air duct assembly from the refrigerator/freezing.
- 2) Remove the sensor.





8.3 Sensor without terminal replacement



Strip off the head of the sensor and connect it.	
Wrap the two wires together with insulation tape.	
Wrap the two wires together.	


8.4 Sensor resistance (R/T)

Tx(℃)	R (KΩ)	Tx(℃)	R (KΩ)	Tx(°C)	R (KΩ)	Tx(°C)	R (KΩ)	Tx(°C)	R (KΩ)
-30	33.81	-15	14.31	0	6.495	15	3.141	30	1.617
-29	31.85	-14	13.55	1	6.175	16	2.999	31	1.55
-28	30.01	-13	12.83	2	5.873	17	2.865	32	1.486
-27	28.29	-12	12.16	3	5.587	18	2.737	33	1.426
-26	26.68	-11	11.52	4	5.315	19	2.616	34	1.368
-25	25.17	-10	10.92	5	5.06	20	2.501	35	1.312
-24	23.76	-9	10.35	6	4.818	21	2.391	36	1.259
-23	22.43	-8	9.82	7	4.589	22	2.287	37	1.209
-22	21.18	-7	9.316	8	4.372	23	2.188	38	1.161
-21	20.01	-6	8.841	9	4.167	24	2.094	39	1.115
-20	18.9	-5	8.392	10	3.972	25	2.005	40	1.071
-19	17.87	-4	7.968	11	3.788	26	1.919	41	1.029
-18	16.9	-3	7.568	12	3.613	27	1.838	42	0.9885
-17	15.98	-2	7.19	13	3.447	28	1.761	43	0.9506
-16	15.12	-1	6.833	14	3.29	29	1.687	44	0.914

9. Function and operation

9.1 Display operation panel

Icon		Button
LED 1:	One gear——COLD (8°C)	A. Temperature setting of refrigerator
LED 2:	Two gear—— \ (6°C)	compartment
LED 3:	Three gear—— \ (4°C)	
LED 4:	Four gear ——COLDDEST (2°C)	



When powered on for the first time, the full display is displayed for 3 seconds, and then it enters the normal operation display, defaulting to the 3rd gear mode (LED3 is on).

9.2 Temperature control

Press the button '**SETTING**' once, the gear will be changed once. 15 seconds after setting, the refrigerator will be running in accordance with the set value.

9.3 MODE SETTING

9.3.1 Super freeze mode

Long press temperature setting button for 6 seconds, it will enter **Super freeze** mode after 15 seconds, and LED3 and LED4 turn on at the same time.

After running for 40 hours at Super freeze mode or the setting button is pressed, it will quit the Super freeze mode, then go back to the previous setting

9.3.2 Super cool mode

Long press temperature setting button for 3 seconds, it will enter super cool mode after 15 seconds,

and LED1 and LED2 turn on at the same time.

After running for 6 hours at super cool mode or the setting button is pressed, it will quit the super cool mode, then go back to the previous setting.

9.3.3 Standby mode

Long press the '**SETTING**' button for 10 seconds, the refrigerator will enter the standby function mode, and the display and control of the refrigerator will be all off.

Long press the 'SETTING' button for 10 seconds again to exit the standby mode.

9.4 Open door alarm (None)

9.5 Fault code and solutions

Display fault code when there is a fault. No longer displaying fault codes after 30 minutes of power on. If there is a fault after 30 minutes of power on, enter the test mode and display fault code for 15 seconds.

Error code	Fault Type	Troubleshooting and Solutions	
LED2 and LED4	Refrigeration	Step 1: Check whether the connection terminals are	
	temperature sensor	plugged in place and whether there are foreign matters in	
flashing	error (E1)	them; after cleaning the terminals, plug them in again.	
LED3 and LED1	Ambient temperature	Step 2: If the fault still occurs, pull out the corresponding	
flashing	sensor error (E7)	connection terminal on the main PCB, use a multimeter to	
		check the resistance value of the sensor, and confirm	
LED1 and LED2 and	Refrigeration defrost	whether it is normal.	
LED4 flashing	sensor error (E4)	Step 3: If the resistance value is wrong, replace the sensor.	
		Step 4: If the fault still occurs, replace the main PCB.	

9.6 Defrosting function

1.Defrost the refrigerator chamber as per the accumulative operation time of the Compressor2.If power failure occurs abruptly to the Compressor,

After that, conduct defrosting according to using condition and ambient temperature in a period between 6 and 36 hours as per the accumulative operation time of the Compressor.

9.7 Test mode

Test items	Testing Method	Expected result
Select to enter into forced cooling mode	Continuously press the refrigeration and temperature adjustment key for 20 seconds, release the key, and enter the forced operation setting mode. The four temperature indicator lights flash, and then continue to press the refrigeration and temperature adjustment key for 7 seconds until the display board is completely off. Press the setting key again to enter the forced operation mode	The gear indicator lights 2, 3, and 4 light up simultaneously, and the compressor is turned on; Normal control of other loads; Operate the compressor in forced operation mode for 72 hours (with a contraction time of 72 minutes), and set the temperature back to the original set gear;

	Drope the button twice continuously in forced	The refrigerator will exit the test mode	
	Press the button twice continuously in forced mode to exit.	and return to normal mode for operation	
Commercial performance mode	Continuously press the refrigeration and temperature control button for 20 seconds, release the button, and enter the forced operation setting mode. The four temperature indicator lights flash, and then continue to press the refrigeration and temperature control button for 7 seconds until the display board is completely off. Press the setting button twice, and the gear indicator lights 2 and 4 will light up simultaneously. After 15 seconds, the display will return to normal display and enter the commercial mode.	The display board is constantly on and the load does not act.	
	Continuously press the refrigeration and temperature adjustment button for 20 seconds, release the button, and enter the forced operation setting mode. The four temperature indicator lights flash, and then continue to press the refrigeration and temperature adjustment button for 7 seconds until the display board is completely off. Press the setting button again 3 times to exit the commercial performance mode		
standby mode	Long press for 10 seconds to enter standby mode In standby mode, press the gear adjustment	All loads are turned off and the display is off;	
	button again to exit standby mode		
Quick cooling mode	Press and hold for 3 seconds to switch to quick cooling mode, which will take effect after 15 seconds;	The quick cooling indicator light is on (LED1/LED2), and the entire machine operates according to the quick cooling start and stop point control; Run in quick cooling mode for 6 hours (with a reduced time of 6 minutes), and set the temperature back to the original set gear	
	In quick cooling mode, press the gear adjustment button again to exit the quick cooling mode		
Quick freezing	; Press and hold for 6 seconds to switch to	The quick freezing indicator light is on	
55219	The same was a second to smill to		

mode	quick freezing mode, which will take effect	(LED3/LED4), and the entire machine
	after 15 seconds;	operates according to the quick freezing
	,	start/stop point control;
		2. When the temperature of the
		refrigeration sensor is less than 5 °C, the
		compensating heating wire remains on.
		When the temperature of the refrigeration
	In freeze mode, press the gear adjustment button again to exit freeze mode	sensor is greater than 5.5 °C, the
		compensating heating wire is turned off.
		3. The quick freezing mode does not enter
		the control of the refrigerated heating wire;
		4. Run in quick freeze mode for 40 hours
		(with a reduction of 12 minutes), and set
		the temperature back to the original set
		gear

10. Compressor

10.1 Compressor on and off Control specifications

10.1.1 All the following conditions are met, and the compressor is turned on

The refrigeration room has reached the start-up point

Compressor shutdown time ≥ 7 minutes (shrinkage time is 7 seconds)

Defrosting sensor temperature ≥ 3.5 °C

10.1.2 The compressor stops when one of the following conditions is met

Tr ≤ Trt

When the continuous shutdown time of the compressor reaches 90 minutes (2 minutes during contraction), the compressor is forced to start, and after reaching the shutdown point and the startup time exceeds 5 minutes (10 seconds during contraction), it is shut down.

10.2 Inverter board fault analysis


Running status of LED Fault Type		Troubleshooting and Solutions	
Not light	Standby	No repair needed	
The light is always on when the power is turned on for the first time, and it is always off after the compressor is turned on and off	Normal working	No repair needed	
Blink once: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second	Software over current protection	Step 1: Disconnect the U-V-W wiring harness, measure the resistance between any two phase of U-V-W terminals (between 5 and 30 Ω and equal in value between any two phase), and measure the resistance between any phase and the fridge metal casing (above 1 M Ω). Step 2: If ok, replace a new inverter board Step 3: If the fault still occurs, replace a new compressor	
Blink twice: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second Blink three times: light 0.5	Overvoltage protection	Measure the voltage between L and N 1) If it is less than 280V, replace a new inverter board 2) If more than 280V, please check the power supply and power cable Measure the voltage between L and N	
second, extinguish 0.5 second, interval time(extinguish) is 2 protection second		 If it is less than 160V, replace a new inverter board If more than 160V, please check the power supply and power cable 	

Blink four times: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second	Hardware over current protection	Step 1: Disconnect the U-V-W wiring harness, measure the resistance between any two phase of U-V-W terminals (between 5 and 30 Ω and equal in value between any two phase), and measure the resistance between any phase and the fridge metal casing (above 1 M Ω). Step 2: If ok, replace a new inverter board Step 3: If the fault still occurs, replace a new compressor
Blink five times: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second	IPM Hardware temperature throttling	In this case, the inverter is usually normal. If the refrigerator cooling function is working, it may be due to insufficient lubrication inside the compressor. If it is not cooling, then there may be a blockage in the refrigeration circuit.
Blink six times: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second	Lack of phase protection	Step 1: Check if the UVW wiring harness is securely connected to the inverter board and compressor. Step 2: Disconnect the UVW wiring harness, measure the resistance between any two phases of UVW terminals. If the resistance between any one or two phases is infinite, replace the compressor. Step 3: Re-power and if the compressor runs for a period of time before tripping, it may indicate a blockage in the piping system. Step 4: If the fault still occurs, replace a new inverter board.
Blink seven times: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second	Voltage bias fault	Step 1: Power off and restart. Step 2: If the fault still occurs, replace a new inverter board.
Blink eight times: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second	Misstep protection	Step 1: After powering on, touch the compressor and wait for the indicator light on the inverter board to light up. Step 2: If the compressor does not respond and the indicator light is flashing, it means the compressor is damaged, replace a new compressor. Step 3: If the compressor shakes when starting and then protects, replace a new inverter board.


Blink night times: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second	Running block protection	Step 1: After powering on, touch the compressor and wait for the indicator light on the inverter board to light up. Step 2: If the compressor does not respond and the indicator light is flashing, it means the compressor is damaged, replace a new compressor. Step 3: If the compressor shakes when starting and then protects, replace a new inverter board.
Blink ten times: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second	Over-temperature and over-power shutdown protection for variable frequency board	In this case, the inverter is usually normal. If the refrigerator cooling function is working, it may be due to insufficient lubrication inside the compressor. If it is not cooling, then there may be a blockage in the refrigeration circuit.
Blink eleven times: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second	Starting failure	Step 1: After powering on, touch the compressor and wait for the indicator light on the inverter board to light up. Step 2: If the compressor does not respond and the indicator light is flashing, it means the compressor is damaged, replace a new compressor. Step 3: If the compressor shakes when starting and then protects, replace a new inverter board.
Blink twelve times: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second	Power and frequency reduction	In this case, the inverter is usually normal. If the refrigerator cooling function is working, it may be due to insufficient lubrication inside the compressor. If it is not cooling, then there may be a blockage in the refrigeration circuit.
Blink thirteen times: light 0.5 second, extinguish 0.5 second, interval time(extinguish) is 2 second	UART communication failure	Check the communication wiring harness between the main control board and the inverter board. If the connection is good, replace either the main control board or the inverter board.

11. Troubleshooting Method


11.1 Error code E0




11.2 Error code E1 / E2 / E3 / E4 / E5 / E7 / E8 / EE / C9 / CC / F4




11.3 Error code E6



11.4 Error code EF



11.5 Error code EH




The meaning of different color wires:

Blue: Ambient temperature

Yellow: Humidity

Red: +5V Black: GND




Comparison table of	output
voltage and humidity	at 25℃
(080) 038%	


Humidity (%)	Output (V)
20	1.528
40	2.067
60	2.779
80	3.400

- Check if the sensor has an correct output voltage between Yellow and Black wires with a multi meter.
- If the value is wrong, please replace it with a new one.


11.6 Error code EP




11.7 Error code CA




11.8 Not cooling in all the chambers




11.9 Poor Cooling in all the chambers




11.10 Overcooling in the refrigerated chamber




11.11 Not & Poor cooling in the refrigerated chamber




11.12 No working of compressor




11.13 Condensation & Frost




11.14 Display panel failure




11.15 Light failure




11.16 No water from the ice & water dispenser



11.17 No ice from the ice & water dispenser



11.18 Noise



12. Maintenance tooling, equipment and material

Tooling

No.	Name	Photo	Main Usage
1	Phillips screwdriver		screw assemble and disassemble
2	slotted screwdriver/scraper		screw and rivet assemble and disassemble
3	Socket spanner 5/16"		hinge and compressor screw assemble and disassemble
4	Sucker		display panel and air duct cover disassemble
5	Allen wrench (2.8~4mm)		handle assemble and disassemble
6	Vise grip pliers		sealing process tube

7	Pipe cutter		pipe cutting
8	Knife	O TIME	assistive tool
9	Nipper pliers		assistive tool
10	Capillary tube scissors		Shear capillary

Equipment

No.	Name	Photo	Main Usage
1	Vacuum pump	YALUE	vacuum pumping
2	Electronic scale		weighing refrigerant/gas

3	High pressure nitrogen with piezometer	pipe and cooling system(condenser, evaporator, etc) impurities clean
4	Soldering gun	heating and welding
5	Quick coupling	connection process pipeline, vacuum or charge refrigerant will be used.
6	hand leak detector	welding point leakage detect, if no, use soap-suds

Material

No.	Name	Photo	Main Usage
1	Process pipeline		Chargetherefrigerant
2	Dry filter		Involving a system failure to be replaced

3	Copper welding rod	tube welding
4	Refrigerant/gas	Add refrigerant to the system
5	Sealing tape	door fixing for reversible door option

13. Product exploded view and spare parts list

Please log in to I-Service system to view and download these contents.

URL: https://ics.midea.com

APAC: https://ics.midea.com
EMEA: https://ics-eu.midea.com

Americas: https://ics-amer.midea.com

