


OWNER'S MANUAL

Ceiling Fan
MODEL: MFC-150A15



Version 1.0 2015

READ AND SAVE THESE INSTRUCTIONS

Attention: Pictures in the IM are for reference only.

INSTALLATION INSTRUCTIONS-CEILING FAN

NOTICE: To ensure the success of this installation, be sure to read the instructions and review the diagram thoroughly before beginning.

GENERAL

After opening the box, you should find the following parts.

- one fan motor ---one regulator
- one down rod ---one set of blades
- two ceiling canopies

Tools required ---pliers
 ---standard screwdriver

SAFETY PRECAUTIONS

1. Installation by licensed electrician is strongly recommended.
2. Be sure electricity off at main switch before wiring.
3. All wiring must be in accordance with national and local electrical codes and this fan must be grounded against possible shock.
4. When fan is mounted, blades must be at least 2.3m from floor.
5. Do not allow hands or other objects to contact rotating blades.
6. This appliance is not intended for use by person (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.)
7. Children should be supervised to ensure that they do not play with the appliance.
8. If the power supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

INSTALLATION INSTRUCTIONS

1. Before beginning, disconnect power by removing fuse or turning off circuit breaker.
2. It is essential that the outlet box or structural member from which the fan is to be suspended will safely support the fan. In view of the torque and weight factors involved. Some outlet boxes will require additional strengthening by securing more firmly to wood beams or steel supports.
3. Screw hook through center of outlet box into beam or roist.
Fix Fork Pipe to the motor shaft. Tighten the bolt and nut firmly.
Make sure the cotter pin is inserted and bent.

4. Tie the safety wire as shown in Figure 1~3 and screw safety wire to the pipe firmly.
5. Safety wire must be tied to 'U' hook.
6. Assemble the other end of the pipe with the pulley to the ceiling hook. Insert the cotter pin and bend

ASSEMBLY INSTRUCTIONS

1. The fan has 3 wires connected to the tip of fan motor.
--- Grounding wire ---power wires
2. Making sure the down rod is locked with setscrew.
3. Mount the fan blades on the motor with lock washer and screw.
4. Make wiring connections with regulators as shown on fig.2.
5. Slide the canopy up to the ceiling and tighten the screw.
6. Turn on the power and your fan will be ready for operation.
7. A contact separation of at least 3mm in all poles should be provided in the fixed wiring for disconnection purpose.

OPERATION INSTRUCTIONS

Remote regulator for ceiling fan is supplied for installation. It is turned clockwise from the mark "1" to "5" indicating the speed from slow to fast while turning counter-clockwise from "5" to "1" indicating from fast to slow. And "0" means off.




FIGURE 1




FIGURE 2

